

## **OORA UNLIMITED TRUCK CLASS RULES Version 1.0**

### **ALL VEHICLES MUST CONFORM TO ALL ACR'S AS STATED IN THE MAIN TECHNICAL RULES SECTION!**

The Unlimited Truck Class is a unique mix of vehicles. It is a combination of Class 3 (SWB 4x4), Class 4 (Unlimited 4x4), Class 8 (Unlimited 2wd) and everything else that does not fit in the other truck classes.

#### **SUSPENSION: NOT ALLOWED:**

1. Active suspension. See ACR16.

#### **SHOCK ABSORBERS:**

- Open STEERING:
- Open BRAKES:
- Open IGNITION:
- Open HEADLIGHTS:

See ACR11. FUEL TANK:

1. Fuel cells mandatory. See ACR14.

#### **ENGINE: Open ALLOWED:**

1. Turbochargers are allowed in diesel engines only.

#### **CARBURETOR:**

##### **Open ALLOWED:**

1. Factory fuel injection.
  - OIL SYSTEM: Open
  - COOLING SYSTEM: Open
  - TRANSMISSION: Open

#### **REQUIRED:**

1. Drive train in stock order. Engine, transmission, transfer case and differential.

CLUTCH AND DRIVE PARTS: Open DIFFERENTIAL AND TRANSFER CASE:

Open SEATS:

See ACR28.

#### **ALLOWED:**

1. Any manufacturer.
  - FIREWALLS: Required. See ACR31.
  - FLOORBOARDS: Required
  - CHASSIS: Frame open. See ACR25.

#### **PICKUP BED: REQUIRED:**

1. External panels only.

#### **OPTIONAL:**

1. Bed floor.

#### **VEHICLE INTERIOR: MANDATORY:**