

OORA UNLIMITED TRUCK CLASS RULES Version 1.0

ALL VEHICLES MUST CONFORM TO ALL ACR'S AS STATED IN THE MAIN TECHNICAL RULES SECTION!

The Unlimited Truck Class is a unique mix of vehicles. It is a combination of Class 3 (SWB 4x4), Class 4 (Unlimited 4x4), Class 8 (Unlimited 2wd) and everything else that does not fit in the other truck classes.

SUSPENSION: NOT ALLOWED:

1. Active suspension. See ACR16.

SHOCK ABSORBERS:

- Open STEERING:
- Open BRAKES:
- Open IGNITION:
- Open HEADLIGHTS:

See ACR11. FUEL TANK:

1. Fuel cells mandatory. See ACR14.

ENGINE: Open ALLOWED:

1. Turbochargers are allowed in diesel engines only.

CARBURETOR:

Open ALLOWED:

1. Factory fuel injection.
 - OIL SYSTEM: Open
 - COOLING SYSTEM: Open
 - TRANSMISSION: Open

REQUIRED:

1. Drive train in stock order. Engine, transmission, transfer case and differential.

CLUTCH AND DRIVE PARTS: Open DIFFERENTIAL AND TRANSFER CASE:

Open SEATS:

See ACR28.

ALLOWED:

1. Any manufacturer.
 - FIREWALLS: Required. See ACR31.
 - FLOORBOARDS: Required
 - CHASSIS: Frame open. See ACR25.

PICKUP BED: REQUIRED:

1. External panels only.

OPTIONAL:

1. Bed floor.

VEHICLE INTERIOR: MANDATORY:

1

.

P